Bell Telephone Laboratories, Incorporated PROGRAM APPLICATION INSTRUCTION

ATATION SPECE

SIZESEG(a)

NAME

sizeseg - get size of segment

SYNOPSIS

(sizeseg = 20.) size = sizeseg(segnum)

DESCRIPTION

Sizeseg returns the size of the segment (in words) indexed by segnum in the process segment table in the PCB.

· SEE ALSO

DIAGNOSTICS

From C, a -1 value is returned if the segment does not exist, i.e. there is no entry in the process's PCB. A fault return with code 10 is generated if *segnum* exceeds the available number of segment table entries.

PA-1C600-01 Section 12 (a) Issue 1, 10/1/77 AT&TCo SPCS

SIZESEG(a)

- 1 -